

### 8.2.3 Cleaning the Tray

1. Turn the Ripple Maker back on.
2. Go to the Preferences menu and tap **Raise Tray for Cleaning**.
3. Clean the surface of the tray.
4. Clean under the tray.
5. Tap **DONE** on the Ripple Maker screen once you have finished all of the above. The tray returns to its resting position.




Figure 8.2: Raise Tray for Cleaning

### 8.2.4 Cleaning the Drip Tray

The drip tray is a metal piece inside the Ripple Maker that collects drops of coffee from the pod.









Figure 8.3: Clean Drip Tray



**1** Tap the  **Preferences** button.

**2** Tap **Clean drip tray**. The pod will move into position.

**3** Lift the lid of the Ripple Maker.



**4** Open the access door.

**5** Slide out the drip tray.

**6** Clean the drip tray with warm water. If necessary, clean the area underneath the drip tray as well.

**7** Dry the drip tray and slide the tray back in.

**8** Close the access door and then return the lid to its proper position.

**9** Tap **DONE** on the Ripple Maker screen once you have finished all of the above.